iris

MARITIME PMS

How-to guides

For the crew

1. Getting started with the Ship App	For the crew
2. Reporting running hours	For the crew
3. Completing a job and recording spare parts	For the crew
4. Reporting a defect with photos	For the crew
5. Noon report, fuel and Quick update	For the crew
6. Hours of rest	For the crew
7. Writing in the Oil, Garbage and Ballast record books	For the crew
8. Condition readings: vibration and temperature	For the crew
9. Tug jobs: All fast and Let go	For the crew
10. Reading and acknowledging circulars	For the crew

1. Getting started with the Ship App

Install the IRIS Ship App on a phone, tablet or the ship's computer, and how it keeps working without internet.

1

Install the app

On **Android**: install the IRIS app from the office (APK), or open **/ship** on your IRIS address in Chrome and choose **Add to Home screen**. On the **Windows** ship PC: install the IRIS Ship App. Any browser works too.

2

Connect the device — once

While online (in port or on Wi-Fi), press **Connect this device** and sign in with your own IRIS account. After that you do not need to sign in each time you open the app.

3

Wait for the vessel data

You will see "*Downloading your vessel data…*". When it is done the tiles appear: **My jobs**, **Running-hour counters**, **Report a defect**, **Noon report** and more, depending on your position.

4

Work offline

At sea everything still works. Each entry goes to the **Outbox** and is sent by itself when there is a signal. The home screen shows how many changes are waiting.

5

Sending

The app syncs every minute when online; you can also press **Sync now**. If you see "*Sync problem*", read the reason — your entry is not lost, it is still on the device.

> **Tip:** Do not uninstall the app or clear the browser data while the **Outbox** still has entries, or the unsent work is lost.

2. Reporting running hours

Why running hours matter and how to report them so that hour-based jobs fall due on time.

1. **Open the counters**

   In the Ship App press **Running-hour counters**. Every counter on board is listed: main engines, generators, compressors and so on.

2. **Type the meter reading**

   Enter the **total hours shown on the hour meter**, not the hours added. If the meter shows 12,450, type 12450.

3. **Save**

   Press **Save readings**. If a value is lower than the last one, IRIS warns you — the reading may be wrong or the meter was replaced. Tell the Chief Engineer if it was replaced.

4. **Do it every day**

   Daily is best, weekly at the least. Running hours move the due dates of hour-based jobs such as overhauls and oil changes.

> **Tip:** If a counter does not move for a long time the system assumes the machine did not run and no job falls due. That is why stale counters appear in the Chief Engineer's alerts.

3. Completing a job and recording spare parts

Close a maintenance job in the Ship App with the findings, the time taken and the spare parts used.

1. **Find the job**

   Press **My jobs**. Jobs are sorted by due date; overdue jobs are red. Open a job to see its steps and readings.

2. **Follow the steps**

   Tick each step when done. Where a reading is asked for (a pressure, a temperature), type it in the box.

3. **Write what you found**

   Use **Remarks** for what was done and found, and enter the time spent. You can **Save** and continue later; it stays on the device.

4. **Add the spare parts used**

   Choose the part and quantity. It is taken off the ship's stock when it reaches the office.

5. **Complete**

   Press **Complete job**. On critical equipment the button reads **Complete & send for verification** — a senior officer or the superintendent verifies it before it counts as done.

> **Tip:** You do not need to wait for internet. The job shows "*Completed (waiting to sync)*" until it is sent.

4. Reporting a defect with photos

Report a fault from the ship, with photos, so that the office sees it at once.

1. **Open Report a defect**

   In the Ship App press **Report a defect**, or **Scan QR** on the machine's label to pick the machine for you.

2. **Choose the machine and severity**

   Pick the equipment and the severity: **Minor** (no effect on safety), **Major** (reduces capability; fix soon) or **Critical** (affects safety, seaworthiness or class). Critical defects are sent to the superintendent at once.

3. **Describe it clearly**

   What you saw, when, and what you have done. For example: "*Oil leaking from the seal of FW pump No. 2, about 1 litre per hour. No. 1 on stand-by.*"

4. **Add photos**

   Add 1–3 clear photos. Offline, the photos are kept and sent with the report.

5. **Send**

   Press **Report defect**. You get a defect number once it is sent, and you can follow it until it is closed.

5. Noon report, fuel and Quick update

Send the noon report (position, distance, fuel) and a quick status update of the vessel.

1. **Open the Noon report**

   Press the **Noon report** tile and choose the type of report: noon, departure, arrival or in port.

2. **Position and distance**

   Latitude and longitude, distance since the last report, hours under way, and ETA.

3. **Fuel**

   Fuel used and remaining on board (ROB) for each fuel. CO_2 and the CII rating are worked out from these figures.

4. **Send**

   Press **Send report**. It works offline and waits in the **Outbox**.

5. **Quick update**

   When the vessel's situation changes (at anchor, loading, stopped), use the quick update tile so that the office sees it in **Fleet Status**.

> **Tip:** Record every bunkering so that the ROB is right. If fuel on board goes up without a bunkering, IRIS warns the office.

6. Hours of rest

Record work and rest every day, and the MLC and STCW rules IRIS checks.

1 Know the rules

Under MLC 2006 and STCW: **at least 10 hours of rest in any 24 hours** and **77 hours in any 7 days**. Rest may be split into **no more than two periods**, one of at least **6 hours**, and the gap between rest periods must not exceed **14 hours**.

2 Open Hours of rest

In the Ship App press **Hours of rest**; on the web, **Safety & Crew → Hours of rest**.

3 Mark the work

Each box is half an hour. Click or drag across the boxes to mark **work** (dark); empty boxes are rest. Pick a watch pattern (for example 00–04 / 12–16) to fill a day quickly.

4 Read the check

The result shows at once: meets the rules or does not, with the reason. If it was an emergency or a drill, say so in the remarks.

5 Sign every month

At month end the seafarer signs and the Master countersigns. Print the **Monthly record (PDF)** for port State control.

> **Tip:** "Any 24 hours" is a rolling window, not midnight to midnight — let IRIS do the counting.

7. Writing in the Oil, Garbage and Ballast record books

Make entries in the electronic record books, and correct one without erasing the original.

1. **Choose the book**

   In the Ship App press **Record books**; on the web, **Record books**, then **ORB I**, **Garbage** or **Ballast**.

2. **Choose the operation code**

   Use the MARPOL code. In the Oil Record Book Part I, for example: **C** for sludge, **D** for bilge water, **H** for bunkering. In the Garbage Record Book: discharge at sea, to a reception facility, or incineration.

3. **Fill in the details**

   Date and time, position (at sea), quantity in m^3, and the tank or category. The form shows what the chosen code needs.

4. **Let IRIS check it**

   A garbage discharge that is not allowed in that area or distance from land (MARPOL Annex V) is refused before it is saved, so a wrong entry never reaches the book.

5. **Corrections**

   Entries are never erased. Press **Correct**: a new entry is made and the old one stays struck through. The Master signs each page.

8. Condition readings: vibration and temperature

Take condition-monitoring readings on board and enter them.

1. **See what is due**

   In the Ship App the **Condition readings due** tile lists the measuring points to read.

2. **Take the reading**

   With the vibration meter or thermometer, measure each point at the same spot and in the same condition each round (for example the same load).

3. **Enter the value**

   Type the value. It turns orange at warning and red at alarm.

4. **On alarm**

   Tell the Chief Engineer at once. It also shows on the bell and in the office's daily e-mail, and a defect can be raised from the point.

9. Tug jobs: All fast and Let go

For tug masters and crews: log the job times for dispatch and billing.

1. **Open Tug jobs**

   In the tug's Ship App press **Tug jobs**. Today's and the next days' jobs are listed: ship, type of job, place and time.

2. **All fast**

   Press **All fast** when the tug is made fast to the ship. The job turns "*Under way*".

3. **Let go**

   Press **Let go** when released, and enter the fuel used if known.

4. **Offline**

   It works without a signal; the time on the device is used even if it is sent later.

> **Tip:** Time is counted in started half hours (1 hour 5 minutes = 1.5 hours). It is the basis of the invoice to the shipping line.

10. Reading and acknowledging circulars

Read circulars and instructions from the office and confirm that you have read them.

1. **Open Circulars**

   In the Ship App the tile shows **Circulars to acknowledge** when there is a new one.

2. **Read it all**

   Open the circular and read it, including any attachment.

3. **Acknowledge**

   Press **I have read and understood**. The date and time are recorded, even offline.

> **Tip:** Some circulars have a deadline. When it passes, the circular appears in your alerts and the Master's.